

## DataSheet


# MT-G292

## MT-G292 PXIe Remote Expansion Card

The MT-G292 is used with MT-X184 or MT-X292 which is inserted in controller slot 1 of the PXIe chassis.



**Caution** Using the MT-G292 in a manner not described in this document may impair the protection the controller provides.



## Dimensions:(mm)

