

MT-P811 背面 100Pin 连接器引脚定义:

PCB RIO-80 IO引脚定义			
功能	引脚		功能
3V	1	2	3V
DIO00	3	4	DIO10
DIO01	5	6	DIO11
DIO02	7	8	DIO12
DIO03	9	10	DIO13
DIO04	11	12	DIO14
NC	13	14	NC
DIO05	15	16	DIO15
DIO06	17	18	DIO16
DIO07	19	20	DIO17
DIO08	21	22	DIO18
DIO09	23	24	DIO19
DGND	25	26	DGND
DIO20	27	28	DIO30
DIO21	29	30	DIO31
DIO22	31	32	DIO32
DIO23	33	34	DIO33
DIO24	35	36	DIO34
NC	37	38	NC
DIO25	39	40	DIO35
DIO26	41	42	DIO36
DIO27	43	44	DIO37
DIO28	45	46	DIO38
DIO29	47	48	DIO39
DGND	49	50	DGND
DIO40	51	52	DIO50
DIO41	53	54	DIO51
DIO42	55	56	DIO52
DIO43	57	58	DIO53
DIO44	59	60	DIO54
NC	61	62	NC
DIO45	63	64	DIO55
DIO46	65	66	DIO56
DIO47	67	68	DIO57
DIO48	69	70	DIO58
DIO49	71	72	DIO59
DGND	73	74	DGND
DIO60	75	76	DIO70
DIO61	77	78	DIO71
DIO62	79	80	DIO72
DIO63	81	82	DIO73
DIO64	83	84	DIO74
NC	85	86	NC
DIO65	87	88	DIO75
DIO66	89	90	DIO76
DIO67	91	92	DIO77
DIO68	93	94	DIO78
DIO69	95	96	DIO79
5V	97	98	5V
5V	99	100	5V

3.3V DIO